

Identify the Solar Panel Mounting Location & Install the Bracket

Choose your location

Pick a spot that receives direct sunlight and no further than 13ft from the Cync Outdoor Battery Camera.

Mark the holes

Hold the bracket against the mounting surface and mark the 3 hole locations with a pencil.

Drill the holes

Use a 1/8" drill bit to drill holes. If using the optional wall anchors, use a 1/4" drill bit.

Mount the bracket

Hold the bracket and screw in the three screws to securely fasten the bracket to your house. If using wall anchors, insert the anchors into the holes prior to mounting the bracket.

Connect the Solar Panel to Your Outdoor Camera

Plug in USB connector to the Camera's USB port

Use the USB connector. Remove the cap and plug into the Cync Outdoor Battery Camera's USB port.

If desired, remove the camera mounting bracket and route the USB cable through the bracket to create a clean appearance.

Note: only use the Cync Outdoor Battery Camera's USB port to connect to the solar panel accessory. If recharging the camera manually, remove the battery and connect the USB charging cable directly to the battery.

