

Like your new CYNC **Smart Camera?** Share your experience!


Leave a review where you








Smart Camera Installation Guide




### Mounting with Screws

Remove Bracket from Bottom of the Camera Identify Placement, Drill Holes




### **Mounting with Removable Adhesive Strips**

Remove Bracket from Bottom of the Camera Identify Placement, Attach Adhesive



## **Mount Camera to Wall**

Mount to Flat, Smooth Surface



### **Incorrect Wall Plate Position**




The Camera can also mount to cellings or upside down. Easily flip the image 180° in the CYNC app for these installations.

# **Incorrect Wall Plate Position**



## **Incorrect Cable and Camera Position**



## **Storing Content on the Camera**



## **Additional Information and Warnings**

FCC Compliance Statement Compliance Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. · Connect the equipment into an outlet on a circuit different from that to

• Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of FCC rules. Operation is subject to the

- This device may not cause harmful interference.
  This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

This device complies with Industry Canada's license-exempt RSSs. Operation is

- This device may not cause interference;
  This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux

- 1. l'appareil ne doit pas produire de brouillage,
- 2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi,

même si le brouillage est susceptible d'en compromettre le fonctionnement. This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Pour se conformer aux exigences de conformité CNR 102 RF exposition, une distance de séparation d'au moins 20 cm doit être maintenue entre l'an<u>t</u>enne de cet appareil ettoutes les personnes.

